


# PLASTICADE® BOLLARD COVERS INSTALLATION INSTRUCTIONS

## Provided Materials:

2 strips of compressible foam, 1/2" x 2" x 60"

1. Clean bollard, removing any dirt or debris.
2. Measure bollard height. Cover should be at least 2" taller than the bollard.
2. Apply the foam strips to the bollard so that they criss-cross at the top of the bollard. Strips should be an equal length down the sides of the bollard.
3. Slide the cover over the foam strips and bollard, applying pressure as necessary to push the sleeve down to the ground.

The foam strips will compress, creating a tight fit.



**Criss-cross foam strips on top of bollard**



**Push cover down over foam strips and bollard**

## Bollard Sizing Guide

4" Cover	Fits Pipe Outside Dia. - 4.5" Pipe Circumference - 14" -15"
6" Cover	Fits Pipe Outside Dia. - 6.625" Pipe Circumference - 20.5" - 21.5"
Heights	52", 60", and 72" Cover should be at least 2" taller than the height of the post.



[Plasticade.com](http://Plasticade.com)