



Installation Instructions



(800) 772-0355
www.plasticade.com


Base Rail Installation

Place Base Rail on top of barrier wall and mark locations for anchor bolts

Do not let the base rail extend past the end of the barrier wall.

Remove base rail and drill holes.




Low spots such as casting marks, must be shimmed with washers to ensure the rail lays flat.



Blade Installation & Removal


Blades snap into rail, no hardware needed.

Place notch in blade under lip in rail. Push down into slots. Push second notch under second rail lip.



Use Removal Tool to remove blades.

Place tool near a blade. Pull back on tool and rail to release blade from rail lip.



Place tool near blade being removed.

Rail Installation Hardware

In cases where the specifications do not have specific requirements, we recommend the use of the following:

3/8" x 3" Simpson Strong Tie Titen HD with
1/2" x 1-1/2" O.D. fender washer

Minimum of 1 anchor required per slot



1/2" x 1-1/2" washer

Simpson Strong Tie
Titen HD
3/8" x 3"
#THD37300H

Attachment hardware and method used to fasten glare screen to barrier should follow state specific regulations where applicable, and is the responsibility of the agency or installer.

Plasticade® Modular Glare Screen



Installation Instructions For X-Cut Rail



Glare Screen can be used on either left or right side of traffic when rail has X-Cut



(800) 772-0355
www.plasticade.com

Left Orientation

Blocks view to left of driver



Right Orientation

Blocks view to right of driver

