

Combcocade Assembly Instructions

1. Assemble the hinge pin for both the left and right legs



2. Insert the bolts through the sheeting and into the top board

3. Place board on legs and apply nuts and tighten, repeat for other side.



4. Repeat for the other 3 boards

